

- | | |
|--|-----------------|
| 1. <u>Motor Assembly (Low Torque)</u> | <u>421206</u> |
| <u>Motor Assembly (High Torque)</u> | <u>421242</u> |
| 2. <u>Brush Kit (High Torque Jones Motor)</u> | <u>421132</u> |
| <u>Brush Kit (Low Torque Motor)</u> | |
| <u>Brush Kit (High Torque Specialty Motor)</u> | <u>42055813</u> |
| 3. <u>Gasket, Motor</u> | <u>421210</u> |
| 4. <u>Timer Assembly</u> | <u>421212</u> |
| 5. <u>Knob, Timer or Speed Control</u> | <u>421213</u> |
| 6. <u>Power Switch</u> | <u>421214</u> |
| 7. <u>Brake Switch</u> | <u>421215</u> |
| 8. <u>Cord Assembly</u> | <u>N/A</u> |
| 9. <u>Cover Assembly</u> | <u>421216</u> |
| 10. <u>Bumpers, Lid (pk of 3)</u> | <u>421203</u> |
| 11. <u>Latch Assembly</u> | <u>421217</u> |
| 12. <u>Lid Cushion (Sold with P/N 421222)</u> | |
| 13. <u>Latch Plate</u> | <u>421220</u> |
| 14. <u>Latch Solenoid</u> | <u>421248</u> |
| 15. <u>Safety Switch</u> | <u>421222</u> |
| 16. <u>Cover, Solenoid</u> | <u>421223</u> |
| 17. <u>Resistor, 50 ohm – 30W</u> | <u>421230</u> |
| 18. <u>Brake Resistor, 25 ohm – 30W</u> | <u>421224</u> |
| 19. <u>Meter Assembly</u> | <u>421225</u> |
| 20. <u>Speed Control Assembly</u> | <u>421219</u> |
| 21. <u>Front Panel Overlay</u> | <u>421209</u> |
| 22. <u>Vibration Isolators (set of 3)</u> | <u>421226</u> |
| 23. <u>Feet, Rubber (set of 4)</u> | <u>N/A</u> |
| 24. <u>P.C. Board Assembly</u> | <u>421231</u> |
| 25. <u>Tachometer P.C. Board</u> | <u>421236</u> |
| 26. <u>Fuse Holder</u> | <u>421229</u> |
| 27. <u>Transformer</u> | <u>421232</u> |
| 28. <u>Relay, K2</u> | <u>421233</u> |
| 29. <u>Interrupter Assembly</u> | <u>421234</u> |

