

1.	Brushes, Motor	42020002
2.	Cord Set	N/A
3.	Cover, Head (w/Knob)	421280
4.	Feet, Rubber	N/A
5.	Gasket, Cover	421269
6.	Gasket, Motor	421264
7.	Gasket, MHCT Tube	421278
8.	Head Fastening Nut	421272
9.	Head Washer	421279
10.	Motor Assembly	
	a. s/n 145000 & up w/gear	421282
	b. s/n 144999 & down w/o gear	421282N
11.	Mode Selector Switch	421270
12.	Lid Assembly	421268
13.	Wrench, Spanner	421275
14.	PC Board Assembly	
	a. s/n 145000 & up	421287
	b. s/n 144999 & down	42020016R
15.	Head Cover, Lower Rubber	N/A
16.	Safety Switch	N/A
17.	Tube Cushion	421276
22.	Transformer	421286T

