

1. <u>Motor Assembly</u>	421375
2. <u>Timer & Knob (Serofuge II)</u>	421379
3. <u>Timer Knob (Serofuge II)</u>	421380
4. <u>Timer & Knob (Serofuge)</u>	421365
5. <u>Brake Switch (Serofuge II)</u>	421196
6. <u>HI/LO Switch (Serofuge II)</u>	421391
7. <u>Hold Switch (Serofuge)</u>	421366
8. <u>Cord Assembly</u>	N/A
9. <u>Cover Assembly</u>	421385
10. <u>Cover Only</u>	N/A
11. <u>Latch & Hardware</u>	421459
12. <u>Safety Switch</u>	421382
13. <u>Latch Block</u>	421395
14. <u>Front Cover</u>	N/A
15. <u>Guard</u>	421387
16. <u>Rubber Channel</u>	421368
17. <u>Spindle Assembly</u>	421367
18. <u>Bottom Cover</u>	N/A
19. <u>Rubber Feet</u>	421388
20. <u>Name Plate (Serofuge II)</u>	421389
21. <u>Name Plate Only (Serofuge II)</u>	421390
22. <u>Governor Brush Assembly</u>	421376
23. <u>Timer & Knob (220v)</u>	N/A
24. <u>Resistor Assembly (Serofuge II)</u>	421125
25. <u>Rubber Seal</u>	421393
26. <u>Spacer</u>	N/A
27. <u>Motor Assembly (220v)</u>	N/A
28. <u>Governor Assembly (Serofuge II)</u>	421377

