

Operator Controls

	Start	The <i>Start</i> button initiates the selected cycle.
	Stop/Open	The <i>Stop/Open</i> button interrupts the cycle and releases the cover when the rotor has stopped.
	2 Minute Cycle	The <i>2 min</i> button selects a cycle of two minutes at 7200 rpm.
	3 Minute Cycle	The <i>3 min</i> button selects a cycle of three minutes at 7200 rpm.
	5 Minute Cycle	The <i>5 min</i> button selects a cycle of five minutes at 5600 rpm.
	Error/Service	The red indicator with an adjacent wrench symbol flashes to signal an error condition or remains continuously illuminated when service is needed.

Error Indicators

Express 3 error conditions are signaled by a flashing red *Error/Service* indicator on the control panel.

The cause of the error condition can be identified by the combination of green cycle time indicators that are also flashing.

