

Spares List

Description	Part number	Quantity	Page reference
The Plinth			
Cableforms: Mains Inlet to Power Supply Unit	A78320021	1	52
Motor Controller	A78320017	1	46
PSU to Processor and Interface PCB	A78320018	1	52
Centralising Spring Kit	A78310015	1	48 / 50
<i>Retainer fixing ring</i>		4	
<i>Spring - extension</i>		4	
Drive Boss Spares Kit	A78310017	1	42
<i>Domed plug</i>		1	
<i>Drive boss</i>		1	
<i>Split collet</i>		1	
<i>Spring washer - M5</i>		1	
<i>Washer - 2BA</i>		1	
<i>Screw - M5 x 10 cap head</i>		1	
Mains Inlet Assembly (note - no fuses included)	77520137	1	52
Motor Controller	AP14339	1	46
Motor Controller Mounting Bracket	A78320011	1	46
Motor Spares Kit	A78310014	1	47
<i>Cable tie</i>		1	
<i>Motor assembly</i>		1	
Moulded Plinth	A78310018	1	44
Out-of-Balance Sensor Kit	A78310013	1	45
<i>Microswitch mounting bracket</i>		2	
<i>Nut - M2</i>		4	
<i>Out-of Balance Detect cableform</i>		1	
<i>Screw - SEM - M3 x 8 pan head pozi</i>		4	
<i>Screw - M2 x 10 pan head pozi</i>		4	
<i>Shakeproof washer - M2</i>		4	
<i>Washer - M2</i>		4	
Processor and Interface PCB	A78310023	1	51
Power Supply Unit	AP14341	1	53
Pull Out Reference Card	A78330014	1	43
Suspension Frame	A78320016	1	48
Wire Rope Mount Spares Kit	A78310016	1	48 / 49
<i>Screw - SEM - M3 x 20 pan head pozi</i>		4	
<i>Screw - SEM - M3 x 12 pan head pozi</i>		4	
<i>Wire rope mount</i>		4	

Description	Part number	Quantity	Page reference
The Case			
Bump Stop (lid)	A78330030	1	60
Cableforms - Display PCB Ribbon Cable	A78320019	1	55
Case Assembly - includes <i>Plastic case</i> <i>Touch panel</i> <i>Display PCB</i> <i>Bump stops</i> <i>Manual release tube</i>	A78310004	1	42 / 43 / 60
Display PCB	A78310022	1	55
Lid Closed Spares Kit <i>Lid Closed Sensor cableform</i> <i>Microswitch</i>	A78310010	1 1 1	59
Lid Lock Sensor Assembly	A78320005	1	59
Lid Lock Spares Kit <i>Splash guard</i> <i>Lid lock assembly</i> <i>Panel rivet</i>	A78310009	1 1 1 4	57 / 58
Lock Solenoid	A78320013	1	59
Keyboard	A78330038	1	56
<hr/>			
The Lid			
Lid Assembly - includes <i>Lid and window assembly</i> <i>Inner liner and seal</i> <i>Lid lock</i> <i>Pivot pins</i>	A78310003	1	60
Lid Hinge Spares Kit <i>Hinge pin</i> <i>Retainer fixing ring</i> <i>Spacer</i> <i>Spring - torsion</i>	A78310011	1 2 2 2 2	62
Lid Seal Assembly Spares Kit <i>Clip</i> <i>Inner liner and seal</i>	A78310012	1 10 1	63
Lid Seal	A78330032	1	63 / 64
<hr/>			

Description	Part number	Quantity	Page reference
The Sealed Head			
Cytoclip Slide Clip	59910052	6	
Inner Bowl	59920046	1	65
Lid Assembly	74010103	1	66
Locking Device Kit	74010104	1	66
<i>Ball</i>		3	
<i>Locking device body</i>		1	
<i>Sealed Head handle assembly</i>		1	
<i>Seal</i>		1	
<i>Screw - M3 x 8</i>		4	
Moulded Lid	P07437	1	66
Sealed Head Hub	59930093	1	65
Sealed Head Seal Kit	59910019	1	65 / Appendix C
<i>(Each Sealed Head requires 3 different seals - this pack includes 1 of each type of seal required)</i>			
<i>Cone Seal</i>		1	
<i>Lid Seal</i>		1	
<i>O-Ring Seal</i>		1	
Support Plate	59920047	1	
Thumb Nut	59930098	1	

Description	Part number	Quantity	Page reference
General Instrument Servicing			
Emergency Access Tool	A78310007	1	
Fastener Kit	A78310008	1	
<i>Cable tie</i>			3
<i>Cable tie holder</i>			8
<i>Domed plug - manual release</i>			2
<i>Dowel pin</i>			2
<i>Foot</i>			4
<i>Panel rivet</i>			4
<i>PCB mounting pillar / washer</i>			4
<i>Retainer fixing ring</i>			4
<i>Screw - SEM - M3 x 6 pan head pozi</i>			4
<i>Screw - SEM - M3 x 8 pan head pozi</i>			6
<i>Screw - SEM - M4 x 10 pan head pozi</i>			6
<i>Screw - M4 x 12 hex head</i>			2
<i>Spacer - M4 male / female</i>			4
<i>Spring - compression</i>			1
<i>Washer - flat i/d 4.3mm; o/d 12mm</i>			4
Fuse Spares Kit	A78310021	1	
<i>T5A, 250V</i>			6
<i>T3.15A, 250V</i>			3
<i>T6.3A, 250V</i>			2
Mains Lead - Europe	P12033	1	
UK	P12031	1	
US	P12032	1	
Operator Guide - English	A78310250	1	
Packaging	AP14378	1	
Service Extension Kit (ribbon cable)	A78320022	1	
Software Download Serial Lead	75220418	1	